

User manual

AP3 diagnostic POD

AP3 diagnostic POD is used for selftest and for testing of calibration values of programmer site.

AP3 diagnostic POD is available as standard accessory for some programmers. The order number: 73-3128.

Selftest of programmer site

Testing sequence:

- Put together Board A with Board B of AP3 diagnostic POD
- Insert AP3 diagnostic POD into Programming Module Interface (PMI) connectors of the programmer site.
- Run selftest of programmer in PG4UW (menu Programmer / Selftest).



AP3 diagnostic POD for Selftest plus

Calibration test

Testing sequence:

- Disconnect Board A from Board B of AP3 diagnostic POD
- Insert Board A of AP3 diagnostic POD into Programming Module interface (PMI) connectors of the programmer site.
- Run calibration test of programmer in PG4UW (menu Programmer / Calibration test).



AP3 diagnostic POD for Calibration test